# Alencon Point of Data Distribution -PODD

*Communication device that provides user interaction for controlling and monitoring alternative energy assets and helps generate more energy from a PV or energy storage installation* 

INSTALLATION, OPERATION AND MAINTENANCE MANUAL FOR THE PODD DEVICE

PM005 Revision 6





Alencon Systems LLC 330 Warminster Rd., Suite 380 | Hatboro, PA 19040 | USA © 2009-2019 by Alencon Systems LLC

This document is the confidential and proprietary information of Alencon Systems LLC. No part of this document may be photocopied, reproduced, stored in a retrieval system, or transmitted in any form or by any means whether electronic, mechanical, or otherwise without prior written permission. Alencon Systems LLC reserves the right to change details in this publication without notice.

**Copyright Information:** Any product names listed in this manual that are not registered trademarks of Alencon Systems LLC and/or organization names mentioned may be trademarks and/or registered trademarks of their respective companies.

### Publication Number: PM005

## Date and Revision

Revision	ECO	Date	Author	Approval	Comment
0	8562	12/10/17	H. Fishman	OF	Original Release
1	8563	12/10/18	P. Shivebankaran	ЦЕ	Modification to incorporate
1	0000	12/19/10	F. Onivshankaran	1 11	new features on SPOT V6
2	8564	6/27/10	T Smiith	ЦЕ	Update to new PODD
2	0304	0/27/19		1 11	features
3	8565	8/23/10	T Smith	ЦЕ	Added installation
5	0000	0/23/13	T. Oniur	1 11	instructions
Δ	8566	11/11/10	T Smith	HE	Added p installation guide
-	0000	11/11/10		1 11	and POE injector guide
					Integrated both PODD and
5	8567	7/19/21	J. Faber	HF	HUB manuals, with
					updated features.
G	0500	0/06/04	l Dohor		Remove Global/Local
0	8008	0/20/21	J.Faper	HF	PODD, added E-Stop.

# 1 Contents

1	Cont	ents	3
2	Con	or Figures	
3	2 4	About This Quide	0
	3.1 2.2	About This Guide	0
	3.Z 2.2	Glossaly	/
	2.0	Toobnical Support and Accistance	0
	3.4 2.5	Warninga, Cautions and Notes	9
٨	3.0	D Kit: Component Parts	10
4		PODD Dovice Available with or without wireless canabilities	10
	4.1		10
	4.2	PODD Sile	10
	4.5	P 1/5 Termination Dongle	11
	4.4	Customized Communication Package Dependent on System Implementation	11
	4.5	Ordering Information	11
5		con Communication Environment ( $\Delta CE$ )	12
0	5 1	PODD Configuration	12
6		D Applications	13
Ű	61	SPOT System	13
	6.2	BOSS System	14
	6.3	GARD System	15
7	POD	D Installation	16
•	7.1	Mounting	16
	7.1.1	PODD Mounting Location	16
	7.1.2	Mounting Parts	16
	7.1.3	Mounting Procedure	16
	7.2	Gounding	18
	7.3	Wiring	18
	7.3.1	Wiring Specifications	18
	7.3.2	Wiring Configurations	18
	7.3.3	PODD Connectors	19
	7.4	Powering	19
	7.4.1	Modbus RTU Power	19
	7.4.2	Network Side PoE Power	19
	7.4.3	Indicator LED	20
	7.5	Establishing a Network Connection	21
	7.5.1	PODD Setup without Network Connection	21
8	E-Ste	p	23
9	Main	tenance and Servicing	24
	9.1	General Maintenance	24
	9.2	Magnet Reset	24
	9.3	PODD Replacement	24
1(	) M	echanical Drawings	25
11	I P	ODD Site	27
	11.1	Introduction	27
	11.2	Version	27
	11.3	Accessing the PODD Site	27
	11.4	PODD Site Features	28
	11.5	Alencon Devices Tab	29

11.5.1 Target Selection	
11.5.2 Command Selection	
11.6 Config Tab	
11.6.1 Steps to Send a Configuration File to the Alencon Device	
11.7 Firmware Update Tab	
11.7.1 Steps to Update Firmware on Your Alencon Device	
11.7.2 Error or Stall Recovery Process	
11.7.3 Firmware Update Status and LOG Messages	
11.7.4 PODD Update	
11.8 Maintenance Tab	
11.8.1 Log Record Management	
11.8.2 Metadata File	
11.8.3 Modbus Register Map	
11.9 Factory Test Tab	
11.10 Settings Tab	
11.10.1 Setting a Static IP Address	
11.11 Device Replacement	
11.11.1 How to Update Metadata File	
12 DCDC Emulator	
12.1 DCDC Emulator Functionality	
12.2 DCDC Emulator Enable and Disable	

# 2 Table of Figures

FIGURE 1: SINGLE PODD DEVICE	
FIGURE 2: PODD SITE, HOME TAB	
FIGURE 3: POE SUPPLY KIT FOR USE WITH PODD	11
FIGURE 4: RJ45 TERMINATION DONGLE	
FIGURE 5: SINGLE PODD CONFIGURATION WITH ALENCON SPOTS	
FIGURE 6: SPOT ACE SYSTEM ARCHITECTURE WITH MULTI PODD CONFIGURATION	
FIGURE 7: BOSS ACE SYSTEM ARCHITECTURE WITH SINGLE PODD CONFIGURATION	
FIGURE 8: GARD ACE SYSTEM ARCHITECTURE (WITH SPOTS)	
FIGURE 9: HOOK SHAPED PODD MOUNTING BRACKET ON UNISTRUT© SUPPORT	
FIGURE 10: STRUCT CHANNEL NUTS ALIGNMENT WITH PODD MOUNTING BRACKET	
FIGURE 11: SCREW PLACEMENT IN STRUCT CHANNEL NUTS	17
FIGURE 12: GROUND LUG PLACEMENT	
FIGURE 13: WATER-PROOF WIRING ON THE PODD	19
FIGURE 14: POE INJECTOR	19
FIGURE 15: POE INJECTOR WITH PODD LAB SETUP	20
FIGURE 16: ANGRY IP SCANNER INTERFACE	21
FIGURE 17: WINDOWS COMMAND PROMPT APP	21
FIGURE 18: COMMAND TO FIND PODD IP ADDRESS	22
FIGURE 19: PODD IP ADDRESS AND PORT IN WEB BROWSER.	22
FIGURE 20: PODD INTEGRATED E-STOP BUTTON	23
FIGURE 21: PODD RESET MAGNET AND GUIDE	24
FIGURE 22: MECHANICAL DIMENSIONS OF THE PODD	25
FIGURE 23: MECHANICAL DIMENSIONS OF MOUNTING BRACKET.	26
FIGURE 24: PODD SITE HOME SCREEN, FIRMWARE VERSION HIGHLIGHTED	27
FIGURE 25: PODD SITE, TAB BAR HIGHLIGHTED	28
FIGURE 26: PODD SITE, DEVICE COMMAND SECTION HIGHLIGHTED	29
FIGURE 27: PODD SITE, DEVICE COMMAND OPTIONS	
FIGURE 28: PODD SITE, DEVICE COMMAND – SET CONTROL	
FIGURE 29: PODD SITE, CONFIGURATION TAB	31
FIGURE 30: PODD SITE, CONFIGURATION TAB – CHOOSE FILE	32
FIGURE 31: PODD SITE, CONFIGURATION TAB – CONFIG DATA	32
FIGURE 32: PODD SITE, CONFIGURATION TAB – WRITE CONFIG	
FIGURE 33: PODD SITE – WRITE CONFIG – LOG MESSAGES	
FIGURE 34: PODD SITE, FIRMWARE UPDATE TAB	
FIGURE 35: PODD SITE – FIRMWARE UPDATE	
FIGURE 36: PODD SITE – FIRMWARE UPDATE STATUS	
FIGURE 37: PODD SITE – PODD FIRMWARE UPDATE	35
FIGURE 38: PODD SITE, MAINTENANCE TAB	35
FIGURE 39: PODD SITE, SETTINGS TAB	36
FIGURE 40: PODD SITE, MAINTENANCE TAB	37

## 3 General Information

All efforts have been made to ensure the accuracy of material provided in this document at the time of release. Items are subject to continuous development and improvements. All specifications and descriptions are subject to change without notice.

## 3.1 About This Guide

### Purpose

This manual provides information about installing, operating, maintaining, and troubleshooting the Alencon PODD device.

### Who Should Read this Manual?

This manual should be read by anyone who needs to:

- Understand the product
- Plan the installation
- Install the product
- Commission the product
- Operate the product
- Maintain the product, as necessary

# 3.2 Glossary

Word(s)/Acronyms	Definition
SPOT	String Power Optimizer and Transmitter
BOSS	Bi-directional Optimizer for Storage Systems
GARD	Ground Arc and Rapid Disconnect
ACE	Alencon Communication Environment
	A full communication system (including hardware and firmware) designed by Alencon to control power conversion equipment.
	Configuration:
	<ul> <li>One PODD, directly connected to a network of wired Alencon hardware, running the user interface</li> </ul>
	<b>NOTE:</b> Wireless packages are available for both Single and Multi PODD configurations
PODD Site/HUB	The terms PODD Site and HUB (stands for Harvesting Utility Block) are used interchangeably throughout
	A software application used to monitor, control, and maintain Alencon hardware, available as a webpage.
	Features:
	Realtime Data Logging and Telemetry
	Alencon Device Control and Configuration
	Firmware Ungrades
PODD	Point of Data Distribution
	The physical networking hardware hosting the website application
	and supporting Modbus TCP communications.

## **3.3 Product Warranty**

Alencon Systems warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for three years from the date of purchase. Extended warrantees are also available for purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Alencon Systems, or which have been subject to misuse, abuse, accident or improper installation. This warranty does not cover the repair or replacement of any goods which fail as a result of damage in transit, misuse, neglect, accident, act of God, abuse, improper handling, misapplication, modification, improper storage, excessive stress, faulty or improper installation, testing or repair, negligent maintenance or failure to comply with the written instructions for installation, testing, use or maintenance (if any) provided by Alencon Systems. Alencon Systems assumes no liability under the terms of this warranty as a consequence of such events.

Because of Alencon Systems's high quality-control standards and rigorous testing, most of our customers never need to use our warranty service. If an Alencon Systems product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult Alencon Systems for more details. If you think you have a defective product, follow these steps:

- 1. Collect all the information about the problem encountered (ie. issues you are encountering in your PV array). Note anything abnormal when the problem occurs.
- 2. Call Alencon Systems or your licensed Alencon Systems dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
- 3. If your product is diagnosed as defective, obtain an RMA (return merchandise authorization) number from your Alencon Systems Technical Support Proffesional. This allows us to process your return more quickly.
- 4. Carefully pack the defective product (preferably in the original packaging material it was shipped in), a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
- 5. Write down the RMA number

## **3.4 Technical Support and Assistance**

Visit the Alencon Systems web site at www.alenconsystems.com where you can find the latest information about the product. Contact your distributor, sales representative, or Alencon Systems technical support if you need additional assistance. Please have the following information ready before you call:

- 1. Product name, serial number (label can be found on the PODD enclosure)
- 2. Description of your peripheral attachments including fusing and cables

## 3.5 Warnings, Cautions and Notes

Warning!	Warnings indicate conditions, which if not observed, can cause personal injury!
Caution!	Cautions are included to help you avoid damaging hardware or losing data.
Note!	Notes provide optional additional information.

## 4 PODD Kit: Component Parts

Alencon will provide a packing list with your shipment. Please make sure to check the packing list matches your order and the items received. Every ACE purchase will include the following components:

## 4.1 PODD Device – Available with or without wireless capabilities

The physical networking hardware that interfaces with Alencon's devices and hosts the PODD website application. The PODD is housed in a hard plastic enclosure that is Nema 3R weather rated for outdoor use.



Figure 1: Single PODD Device

## 4.2 PODD Site

Firmware pre-loaded to the PODD that hosts the user interface, accessible through any PC connected to the same network as the PODD.

Local PODD Site



Figure 2: PODD Site, Home Tab

## 4.3 PoE Supply Kit

A PoE injection dongle and DC power supply for powering the PODD device. More information on how to use can be found in section 7.5.2.



Figure 3: PoE Supply Kit for use with PODD

## 4.4 RJ45 Termination Dongle

Terminating resistors for the modbus communications line are used for reduction of noise in the communciation infrastructure. The RJ45 dongle should be installed at the end of the modbus RTU daisy chain (see section 7.4.2).



Figure 4: RJ45 Termination Dongle

## 4.5 Customized Communication Package – Dependent on System Implementation

Various antennas and cables can be purchased for wireless and wired configurations, respectively. Each communication package will be customized per order to ensure the correct hardware is provided for specific implementations. This includes making sure the correct antenna is supplied depending on where PODDs will be mounted or the specific length and type of cabling needed for installation.

## 4.6 Ordering Information

Model Number	Description
PODD	Point of Data Distribution device with website UI
Wifi Access Point	Wifi Acccess Point for use with PODD if wireless communucations is being used
Communication	Customized package that provides the correct number of antennas
Package	and cables needed for installation

## **5** Alencon Communication Environement (ACE)

The PODD can be used in different configurations, depending on application and communications needs. A full communications system, designed by Alencon, is sometimes referred to as 'ACE'.

### **Communications Protocol:**

Alencon devices support Modbus RTU communications to the PODD. The PODD converts Modbus RTU to Modbus TCP for external controller or SCADA integration.

### **Communications Hardware:**

All configurations use Cat5e or newer ethernet cables of STP type. Each string of Alencon devices will be terminated with an RJ45 terminator to reduce noise and reflections. More information on wiring and cable spec can be found in section 7.4.1.

## 5.1 PODD Configuration

In this configuration, a single PODD is connected to a string of Alencon devices which will supply power and transmit data to the PODD using Modbus RTU. The PODD will also be connected to a local area network and provide a user interface to communicate with the Alencon devices directly.



Figure 5: Single PODD configuration with Alencon SPOTs

## 6 **PODD** Applications

The PODD is ideal for commercial or utility scale photovoltaic (PV) systems that have Alencon power conversion devices including the SPOT, BOSS, and/or GARD. This section details how each of Alencon's devices can be connected over a network using the PODD.

## 6.1 SPOT System

Alencon's String Power Optimiziers and Transmitters (SPOTs) have up to four inputs and can accommodate from 4 to 8 strings. Depending on the size and need of a PV array, the SPOTs can be setup with a Single or Multi PODD configuration.



Figure 6: SPOT ACE System Architecture with Multi PODD configuration

## 6.2 BOSS System

Alencon's Bi-Directional DC-DC Optimizer for Storage Systems (BOSS) controls the charge and discharge of individual battery racks with a galvanically isolated approach. BOSSs are generally co-located and easily daisy chained to a PODD. An example BOSS system architecture using a Single PODD configuration is shown in Figure 10.



Figure 7: BOSS ACE System Architecture with Single PODD configuration

## 6.3 GARD System

Alencon's Ground Arc and Rapid Disconnect (GARD) System is a protection device to detect harmful arc and ground faults in PV arrays. These can be configured as stand-alone protection or be paired with other Alencon devices (ie. SPOT or BOSS).



Figure 8: GARD ACE System Architecture (with SPOTs)

**NOTE:** Each type of device (SPOT, BOSS, and GARD) can have communications daisychained with any other type of device and still connected to a Local PODD.

## 7 PODD Installation

This section provides information on how to install a PODD in the field and access the PODD site user interface.

A single PODD is installed at one end of a daisy chained RS-485 network. The total length of the cabling should not exceed 100 meters. An antenna will be included for the PODD if wireless package is purchased.

## 7.1 Mounting

Each PODD will be shipped with the mounting bracket already installed.

### 7.1.1 PODD Mounting Location

PODDs will be mounted on-site near the strings of Alencon devices.

### 7.1.2 Mounting Parts

The PODD can be easily mounted using standard Unistrut© along with spring loaded channel nuts. The attached hook shaped bracket allows for the PODD to be easily hung on the unistrut and then fastened using a Hex hed screw. Recommended hardware for mounting is as follows:

- Unistrut© Any typical zinc plated or galvanized steel unistruts
- Strut Channel Nuts with Spring, 13/16" Channel High, 5/16-18 x2 per PODD
- Hex Head Screw, Grade 8 Steel, 5/16"-18 Thread Size, 1" Long x2 per PODD

### 7.1.3 Mounting Procedure

To install the PODD in the field:

1. With the Unistrut© support structure already in place, hang the PODD mounting bracket on the top channel.



Figure 9: Hook shaped PODD mounting bracket on Unistrut<sup>®</sup> support

2. Next, align the bottom mounting holes on the PODD bracket with the bottom channel and struct channel nuts.



Figure 10: Struct channel nuts alignment with PODD mounting bracket

3. Finally, secure the PODD in place by placing the screws into the stuct channel nuts.



Figure 11: Screw placement in struct channel nuts

## 7.2 Gounding

The external ground lug is found next to the three RJ45 connectors on the bottom of the PODD. The ground lug can be loosened and tightened with a standard flathead screwdriver. This **MUST** be connected to Earth ground. Not properly grounding the PODD can cause the PODD to malfunction and be damaged.



Figure 12: Ground lug placement

## 7.3 Wiring

### 7.3.1 Wiring Specifications

The PODD and connected hardware should all be compatible with the following spec:

- **RS-485 (4 wire) standard** defines the necessary electrical characteristics of cabling, transmitters and recievers. All Alencon devices, including the PODD, have internal hardware compliant with RS-485.
- **STP Cat5e (or better) cable** other RS-485 compliant cable types can be used, but Cat5e is most common. Note that Cat5e cables will have a max run length of 100m.
- **RJ45 T-568B connector** all communications ports on Alencon devices accept male RJ45 connectors as input.

## 7.3.2 Wiring Configurations

### Single PODD Configuration:

- Connect a cable between the Modbus RTU port on the PODD and the Alencon devices. All Alencon devices can be daisy-chained together.
- Connect the RJ45 termination dongle to the final Alencon device on the Modbus RTU daisy chain.
- For Wired: Connect a cable between the WAN port on the PODD and a nearby Ethernet switch.
- For wireless: Connect the purchased antenna to the adapter on top of the PODD.

### 7.3.3 PODD Connectors

Each PODD has three ports which are labeled on the bottom of the front mounting plate. To connect a cable to any of these ports:

- 1. Remove the water proof cap and grommet.
- 2. Feed the cable though the removed cap and grommet.
- 3. Replace the cap and grommet, tightening to reseal the port.



Figure 13: Water-proof wiring on the PODD

## 7.4 Powering

### 7.4.1 Modbus RTU Power

The PODD is most commonly powered via a 24V signal from the networked Alencon device (SPOT, BOSS, or GARD). Simply connect a Cat5e (or newer) cable between the peripheral device comms port and the PODD ModbusRTU port. PODD should turn on within 2 minutes and green LED indicator will turn on when ready.

## 7.4.2 Network Side PoE Power

When using the PODD in a lab setup where power from Alencon devices is not readily available, a POE injector is a convenient solution. A POE injector combines a network connection and power into an RJ45 port as seen below.



Figure 14: POE Injector

When using a POE injector to power the PODD, the male end of the POE injector should be connected to a network switch and the female end should be connected (via a Cat5e or better cable) to the WAN port of the PODD. The PODD will take a couple minutes to boot up and the LED indicator will turn green when ready.



Figure 15: POE Injector with PODD Lab Setup

### 7.4.3 Indicator LED

The large LED on the PODD front face is used to indicate the status of the PODD:

- OFF PODD has not turned on or has no input power
- GREEN Normal Operation (PODD is on and UI is available)
- RED Error (low input power, UI not frozen, etc.)

## 7.5 Establishing a Network Connection

PODDs are accessed remotely over your local server using IPv4 addresses. For the initial setup, download a network IP scanner of your choice. A recommended IP scanner is *Angry IP Scanner* which can be downloaded from <u>https://angryip.org/download/</u>. Once installed and opened, your local IP Range should automatically be set. Hit the start button to scan your local network for PODDs.

Gan Go to Co	gry IP Scanner mmands Favori	es Tools Help		—
IP Range:	to	IP Range 🗸 🌣		
IP	Ping	Hostname	Ports [0+]	
Ready		Display: Alive only T	hreads: 0	

Figure 16: Angry IP Scanner Interface

When a PODD is found, it will appear under the "Hostname" column as PODD-xxxx where the 'xxxx' will be the last four digits of its serial number. Locate the IP address of that PODD and type the IP address followed by **:8888** (ex. *123.456.789.012:8888*) into the url bar of your favorite web browser. The PODD site should be accessible and the PODD install complete.

### 7.5.1 PODD Setup without Network Connection

Sometimes it is necessary to use a PODD without connecting it to a network, especially if the PODD will be moved around and not be mounted to a specific row of Alencon Devices. To establish a connection with a mobile laptop, connect the PODD's WAN port to the Ethernet port of the laptop. The next step is to find the IP address of the PODD through the PC:

1. First open up the command prompt of your windows machine



Figure 17: Windows Command Prompt App

 Locate the serial number of the PODD from its physical label. Look at the last four digits of the serial number and try to ping the PODD through the following command: 'ping -4 PODD-xxxx' where the 'xxxx' will be the last four digits of its serial number. The PODD IP address should appear



Figure 18: Command to find PODD IP address

- 3. Locate the IP address of that PODD and type the IP address followed by **:8888** (ex. 123.456.789.012:8888) into the url bar of any of the following web browsers:
  - a. Google Chrome
  - b. Microsoft Edge
  - c. Apple's Safari
  - d. Mozilla Firefox
- 4. The PODD site should be accessible and the PODD install complete.

Local PODD Site



HUB Version 18.2.158 - Copyright Alencon Systems, LLC 2020

Figure 19: PODD IP address and Port in Web Browser

## 8 E-Stop

Alencon power devices (SPOT, BOSS, and GARD) can employ an external emergency stop button, that utilizes the PODD and communications cabling to deliver an E-Stop signal. The PODD will have an E-Stop button integrated as part of the enclosure (see figure 19) that when engaged (pushed-in) will automatically force the connected units into Shutdown mode, and when disengaged (pulled-out) will allow the units to operate once more.



Figure 20: PODD Integrated E-Stop Button

The E-stop button employs a normally closed (NC) switch, so if any disconnect occurs on the line, devices 'downstream' from the PODD will go to Shutdown state.

## 9 Maintenance and Servicing

## 9.1 General Maintenance

Follow these recommendations to ensure optimal performance of the system.

- Make sure the PODD and mounting bracket are fastened securely
- Make sure that the PODD enclosure is sealed completely
- Do not stress any connectors, wires or antennas

## 9.2 Magnet Reset

There is a magnetic reset switch placed inside the enclosure on the upper rightside. To toggle this switch, the enclosure **DOES NOT** need to be opened. Look for a utility magnet to be mounted on the PODD enclosure. The magnet reset should be used as a first line troubleshoot when there are issues with the PODD or PODD-Site UI.

To reset the PODD, follow the label and run a magnet down the right side of the PODD enclosure from position 1 to 2. The status LED will turn off to indicate a system reboot is occurring. After a couple of minutes the PODD will turn back on, the green LED indicator will be on, and the PODD site will be accessible.



Figure 21: PODD Reset Magnet and Guide

## 9.3 PODD Replacement

PODDs come preconfigured from Alencon. If the PODD requires servicing, disconnect and obtain an RMA (return merchandise authorization) number from Alencon Systems technical support. Then following the RMA process, return the defective PODD to Alencon Systems or an authorized Alencon service agent.

# **10 Mechanical Drawings**







Figure 23: Mechanical Dimensions of mounting bracket

## 11 PODD Site

Every PODD comes pre-loaded with a website based user interface that is accessible through any PC connected on the same network as the PODD. The software allows interaction from a PC to a given Alencon device (including the SPOT, BOSS or GARD).

## 11.1 Introduction

This document describes the uses and benefits of the PODD Site application, including the following functionality:

- Telemetry Viewing
- Telemetry Logging
- Command Sending
- Configuration Setting and Retrieval
- Log Message Display
- Firmware Update
- Modbus TCP Server

## 11.2 Version

This manual is meant for use with PODD Site Version 18 and newer. You can always see the version you are using from the Home screen:

Local PODD Site



Figure 24: PODD Site Home Screen, Firmware Version Highlighted

## 11.3 Accessing the PODD Site

The PODD site is accessed from a Windows PC using the IP address of the PODD which can be found by scanning your local network. The detailed explanation of connecting to and accessing the PODD Site can be found in section 7.5 above.

## **11.4 PODD Site Features**

The PODD Site has seven tabs, that can be accessed by clicking on their name along the tab bar at the top of the page:

- 1. Home
- 2. Alencon Devices
- 3. Config
- 4. Firmware Update
- 5. Maintenance
- 6. Factory Test
- 7. Settings



HUB Version 18.2.158 - Copyright Alencon Systems, LLC 2020

Figure 25: PODD Site, Tab Bar Highlighted

## 11.5 Alencon Devices Tab

The Alencon Devices tab provides a list view of the Alencon Devices connected to the PODD in the field and their individual DCDC data. The Alencon Devices can be controlled as a field set (Field Broadcast) or independently using commands from the Device Command drop-down menu in the Alencon Devices tab.

Home	Alencon Dev	vices Config Firmware Update Maintenance	Facto	ry Test Settings		
Devic	e List				Device Information	
	Device	GUID	LIN	Status	Parameter	Value
0	SPOT	8760150274862898243	1	DEFAULT	Output Index	0
۲	GARD	7720944416032130101	2	SHUTDOWN	Device LIN	2
					Output Combiner ID	1
					Parent Unit Address	0
					Comms SN	0
					DCDC Board SN	
					Device SN	0000-00-0000-0000
					GUID	7720944416032130101
					Device Type	GARD
					Input Disconnect ID	0
					Modbus Unit Address	2
					Input String ID	0
					Input Index	0
					Inverter ID	2205A
					Device Command Target: Selected Device ~ Oblected Device Comma Field Broadcast	✓
					Send Command	

Figure 26: PODD Site, Device Command Section Highlighted

### 11.5.1 Target Selection

Select the Device to command. The targets available are:

- 1. Selected Device: Send a command to the individual selected from the device list
- 2. Field Broadcast: Broadcast the command to all the devices in the list

### **11.5.2** Command Selection

The PODD Site provides a broad set of operational and diagnostic commands. Do not use unlisted commands unless instructed to do so by Alencon personnel. Failure to do so may damage the Alencon device and void the warranty.



Figure 27: PODD Site, Device Command Options

- 1. **System Reset** Restarts the Alencon Device and enables Run if in the Shutdown state.
- 2. **Shutdown** Disables power production. The Alencon Device or DCDC must receive a System Reset command to enable Run.
- 3. Precharge DO NOT USE
- 4. Run DO NOT USE
- 5. **Standby** DO NOT USE. Puts the Alencon Device into STANDBY mode, Run is enabled without a System Reset command.
- 6. **Clear Fault** This command clears all error flags on the target selected. Note: It is not necessary to clear faults for the Alencon Device to run.
- 7. Test Mode On DO NOT USE
- 8. Test Mode Off DO NOT USE
- 9. Set DCDC Frequency DO NOT USE
- Set Control Main control operations for BOSS (and SPOT in some cases). A submenu of commands are used to choose the Control Mode, Setpoint, Direction (for BOSS only) and Setpoint Timeout.

### **Device Command**

#### **Device Command**

Target: Selected Device 🗸	Target: Selected Device V	
Command: Set Control	Command: Set Control	
Control Mode: PRIMARY POWER	Control Mode: STANDBY	
Setpoint: 5	Setpoint: 5 MANUAL	
Direction: $\bigcirc$ Primary to Secondary $\bigcirc$ Secondary to Primary	Direction:  PRIMARY CURRENT SECONDARY CURRENT Direction:	lar
Setpoint Timeout: 0 sec	Setpoint Timeo PRIMARY VOLTAGE SECONDARY VOLTAGE sec	
Send Command	Send Comman SECONDARY POWER	

- 11. Reset Modbus address to 247 (Default) This command resets the Modbus address of the Alencon device within a page to default. The customer would then have to re-define the Modbus addresses of each DCDC using the "metadata" file. The file must be edited using Notepad++ or any other text editors (contact Alencon for training on this).
- 12. (Only for GARD) GARD Write flags A, Write Flags B, Clear Flags Flags A & B for the GARD are read/write registers that display the status of internal control signals and faults. These specific commands can only be used in "Testmode" typically for debug and lab tests.

## 11.6 Config Tab

The Config Tab allows the user to update the configuration on the select Alencon Device. A configuration files is provided to the user in a '.factory' file and it comes preloaded on the Alencon Device – i.e. SPOT, BOSS or PODD. This file contains specific parameters for your deployment of Alencon devices. Do not edit these parameters unless asked to do so by Alencon personnel. **Failure to follow these instructions may damage the Alencon Device and will void the warranty**.

 Home
 Alencon Devices
 Config
 Firmware Update
 Maintenance
 Factory Test
 Settings

 Choose File
 No file chosen

 GARD GUID: 7720944416032130101 LIN 2 v)
 Get Config From Device
 Load Config From File

 Write Target:
 Single Device v)
 Write Config

Device Log Messages:

Figure 29: PODD Site, Configuration Tab

The Alencon devices are selected by GUID, a unique identifier of each DCDC. (The Alencon device LIN can be found in the Alencon devices tab). Configuration can be written to the whole field or a single DCDC:

- Single Device: Configures the individual DCDC for the selected GUID
- Whole Field: Configures all DCDCs and communication in the entire field

## **11.6.1** Steps to Send a Configuration File to the Alencon Device

 Choose the file you would like to send to the Alencon Device by clicking the **Choose File>** button. This file has a '.factory' extension. Note: The factory file is a standard json object that is viewable with any text editor.

Nume       Status       Determodified       Type       Size         MyT Client: Connected       With Connected       If		Loc	cal PODD Site -	<b>Configuratio</b>	n		
	Home         Alencon Devices         Ceaning         Firm ware Update         Maintenance         Factory Teat           Choose File         No file chosen         SPOT GUID: 0760150274802892421 LW T ••)         Get Contig From Device.)         Load Contig From File           Write Target:         Singo Device ••)         Write Contig         Load Contig From Device.)         Load Contig From File           Device Log Messages:	Open	Documents > Configs	Date modified 3 11/11/2020 11:13 AAM 6	y P Search C ype SACTORY File	ionfigs IEE + T Size 7 KB	×
File name V All Files		File name:			✓ All Files Open	Cancel	

HUB Version 18.7.16 - Copyright Alencon Systems, LLC 2020

Figure 30: PODD Site, Configuration Tab – Choose File

- 2. Select the GUID of the target Alencon Device. The LIN to GUID mapping can be found on the Alencon Devices tab.
- 3. Once you load the config file click **<Load From Config File>** to see the configuration parameters. You will have the option to modify the parameters without editing the file if necessary (only do this if instructed to do so by Alencon).

	Loc	al PODD Site - Configuration	
Home Alencon Devices Config Firmware Update Maint	enance Factory Test Settings		
Choose File No file chosen GARD GUID: 7720944416032130101 LIN 2 • Get Config From Device Load Write Turset: (Single Davice v) Write Config	Config From File		
Device Log Messages:	GARD Con	ñg	
MQTT Client: Connected	Parameter		Value
	ct_on_threshold	_amps	0
	start_timeout_s	econds	1
	afd_enable_three	shold_amps	0
	config_version		18
	baud_rate		115200
	ground_fault_m	in_kohms	16000
	enable		0
	always_bootup_	in_shutdown_state	0
	standby_delay_s	econds	30
	comms_timeout	_seconds	0
	ground_fault_cu	rrent_amps	1.2
	flags_c		0
	flags_d		0
	board_otp_deg_	c	90
	ct off throshold	1 ampr	0

Figure 31: PODD Site, Configuration Tab – Config Data

4. The final step is to send the loaded configuration to the Alencon Device. To do so, click **<Write Config>**.



Figure 32: PODD Site, Configuration Tab – Write Config

5. Look for log messages that confirm the configuration is successfully sent and verified on the device.

### **Device Log Messages:**

```
MQTT Client: Connected

08/04/21 14:57:06 address 1: CONFIG Config successfully sent to device 1

08/04/21 14:57:06 address 247: <u>PODD GENERAL Config successfully sent to devices: [1]</u>

08/04/21 14:57:12 address 1: BOSS_GENERAL DCDC templ range issue, val 39.09, ave 24.09,

buf [24.92 24.96 25.01 25.05 24.79 24.83 24.88]

08/04/21 14:57:16 address 247: <u>PODD GENERAL Config verification successful for devices:</u>

[1]
```

Figure 33: PODD Site – Write Config – Log Messages

## 11.7 Firmware Update Tab

The Firmware Update tab allows the user to update the firmware installed on the Alencon device over the network.

Home Alencon Devices Config Primovare Update Maintenance Factory Test Settings									
Choo	Closes File Ito Buckson								
	Short	LIN	GUID	Alencon Device					
8	1	10	8868236880668417090	undefined					
	2	11	8868236833420106818	undefined					
8	3	12	8868236833423907906	undefined					
	4	13	491541573757197378	undefined					
	5	14	491541526515244098	undefined					
	6	15	8800682839013874754	undefined					
8	7	16	234836339165649986	undefined					
8	8	17	868823633419779138 undefined						
Upda Sel Firi	Ugdata Finnuse) III Select All Ged Wanine   Abort Update on HUB   Reset Update State on Device   Reset Target Firmware Update Status:								
Dev	Device Log Messages:								
MQTT Client: Connected									

Figure 34: PODD Site, Firmware Update Tab

## 11.7.1 Steps to Update Firmware on Your Alencon Device

Alencon may release newer firmware versions that fix bugs or add new features. Please follow the below instructions carefully to update your Alencon devices.

You will be provided with a set of files required to update the firmware on your Alencon device if need. *Alencon recommends that you upgrade all processors and all devices in a field with the same firmware version to ensure compatibility within and between devices.* 

Choose File No file chosen										
	Short	LIN	GUID	Alencon Device						
	1	10	333915539552885826	fw_17.18.18 boot_5.7 git_80f8c56a76782ab2						
Update Firmware										
Select All Get Version Abort Update on HUB Reset Update State on Device Reset Target										

Firmware Update Status:

#### Figure 35: PODD Site – Firmware Update

- 1. Select the devices you wish to upgrade.
- 2. Click on **<Get Version>** to verify communication is working and check which version is loaded on the device.
- 3. Click <Choose File> and find the corresponding .zip file for the target
- 4. Click <Update Firmware>
- 5. See the progress bar corresponding to the update process.

### 11.7.2 Error or Stall Recovery Process

If the firmware update stalls or has an continuous error, follow this procedure carefully to insure a minor error does not become unrecoverable:

- 1. Click < Abort Update on HUB>
- 2. Copy the SPOT and Firmware LOG Messages to text editor such as Notepad, save, and send to Alencon. This will help diagnose the failure.
- 3. Click <Reset Update State on Device>
- 4. Retry the update. Contact Alencon if the update fails again.

### **11.7.3 Firmware Update Status and LOG Messages**

The status and log messages provide real time feedback on the update state. The firmware update can be in 1 of 4 states:

- 1. Idle: Not in the batch update queue
- 2. Pending: Waiting in the queue
- 3. Completed: Updated successfully
- 4. Failed: Update Failed

## Firmware Update Status:

Update State: updating, [1] Pending: [1] Completed: [] Failed: []

#### Figure 36: PODD Site – Firmware Update Status

These messages provide the user the status of the SPOT during the update process and if the update is complete or failed.

### 11.7.4 PODD Update

The PODD Site itself may have newer firmware versions that fix bugs or add new features. To update the PODD Site firmware:

- 1. Click **<Choose File>** and find the .zip file containing the proper PODD firmware
- 2. Click **<Update PODD>** and watch for the progress messages in the device log
- 3. After the update completes 100%, wait for the PODD to reboot fully
- 4. Refresh the PODD Site and see the new firmware version verified at the bottom of the webpage

PODD Update:

Device	Status	Upload
PODD		Choose File PODD_Firmware_15.8.4 zip Update PODD
Device Log Messages:		
00TT Climat: Connected 00TT Climat: Connected 0021142623 address 247: PODD_CEXTERAL PODD Update Progress: 10% 0021142623 address 247: PODD_CEXTERAL PODD Update Progress: 30% 0021142636 address 247: PODD_CEXTERAL PODD Update Progress: 30% 0021142636 address 247: PODD_CEXTERAL PODD Update Progress: 50% 0021142637 address 247: PODD_CEXTERAL PODD Update Progress: 50% 0022142637 address 247: PODD_CEXTERAL PODD Update Progress: 50% 0022142637 address 247: PODD_CEXTERAL PODD Update Progress: 50% 0022142637 address 247: PODD_CEXTERAL PODD Update Progress: 10%% 0022142637 address 247: PODD_CEXTERAL PODD Update Progress: 10%%		

Figure 37: PODD Site – PODD Firmware Update

## 11.8 Maintenance Tab

Local HUB - Maintenance								
Home Alencon Devices Config	Firmware Update Maintenance	Factory Test Settings						
Log Record Management								
Start Range: mm/dd/yyyy 12:00 AM	(Leave blank to select from begin	ning)						
End Range: mm/dd/yyyyy 11:59 PM	(Leave blank to select until end)							
Log Type: [Telemetry Records • [Dominand Log] Delete Key ('delete*): Delete Log Meta Data and Modbus Register Map								
File	Download	Upload	1					
Meta Data	Download Meta Data	Choose File No file chosen Upload Meta Data						
Modbus Register Map	Download Modbus Register Ma	Choose File No file chosen Upload Register Map						
herin Las Messaer								

Figure 38: PODD Site, Maintenance Tab

The Maintenace Tab allows for a variety of house-keeping functios:

- Log message and telemetry record retrieval
- Log message and telemetry record deletion
- Metadata update and retrieval
- Modbus Register Map update and retrieval

### 11.8.1 Log Record Management

Log messages and telemetry are stored in an internal data base. When an export request is made, the database is queried, the records are exported to a csv, and then compressed. This process can take a couple of minutes if the query is large. Please be patient.

It is typically unnecessary to delete records unless instructed to do so by an Alencon representative. The PODD Site internally limits the physical size of the database and the age of all records. These settings are found in the Settings Tab.

### 11.8.2 Metadata File

The Metadata file describes the mapping of GUID to other associated data such as LIN and Modbus address. This file will need to be updated with the new GUID when ever an Alencon device is replaced. Procedure for this can be found in section 10.11.1

### 11.8.3 Modbus Register Map

This file defines the mapping of modbus registers to Alencon device's internal data types and scaling. This file will almost never need modification.

## 11.9 Factory Test Tab

If you have purchased Alencon's protection device i.e. the GARD then the Factory Test tab may be of use otherwise do not use. More information can be found in the GARD user manual.

## 11.10 Settings Tab

The settings tab contains PODD configuration settings. Alencon personnel will guide you through any settings updates. Click **<Restart HUB>** to reboot the PODD site application.

Home Alencon Device	es Config Firmware Update	Maintenance	Factory Test	Settings				
UB Settings								
Requires reset of HUB for s	etting change to take effect							
etting Name	Value		Descri	ption				
uto_clear_errors	Ø *		Autom	atically <mark>clea</mark>	ars device errors			
actory_key			Key fo	factory				
eld_name	field_dummy		Name	of field POD	D is in			
ub_log_level	debug	•	Possib	e values are	e debug, info, warning, and error			
ub_name	Local PODD Site		Name	Name for HUB Site				
nodbus_port	502 *		Port n	mber for M	odbus TCP server			
nqtt_websockets_port	1884		Port fo	r websocke	ts MQTT connection			
odd_name	podd_dummy	•	Name	of PODD				
roject_name	project_dummy	*	Name	of project f	or PODD			
atic_gateway	0.0.0.0		Gatew	ay for static	: IP for PODD			
tatic_ip_address	0.0.0.0		Static	P Address f	or PODD			
atic_netmask	0.0.0.0		Netma	sk for static	IP for PODD			
pdate Settings Restart HU	в							

Figure 39: PODD Site, Settings Tab

### 11.10.1 Setting a Static IP Address

By default, the PODD will have a dynamically assigned IP address, which corresponds to a value of "0.0.0.0" for the parameters "static\_gateway", "static\_ip\_address", "static\_netmask".

To set a static IP address:

- 1. Change parameters to the desired values
- 2. Click **<Restart HUB>** to reboot the PODD Site. Note: the new values should be recorded in case of an error.
- 3. PODD Site should now be accessible at the new IP address.

## **11.11 Device Replacement**

When a networked Alencon device is replaced the associated GUID to LIN and Modbus Address mapping on the PODD Site must be updated. The mapping is stored in the Metadata .csv file. Alencon personnel will provide you a new Metadata file corresponding with the replaced device.

### 11.11.1 How to Update Metadata File

To update the metadata file:

- 1. Go to the Maintenance tab
- 2. Click <Choose File> and select the newest .csv metadata file
- 3. Click <Upload Meta Data>

Home	SPOTs	Config	Firmware Up	odate N	Aaintenance	Factory Test	Settings					
Log Re	ecord Ma	inagen	nent									
Start Rang	tart Range: mm/dd/yyyy 12:00 AM (Leave blank to select from beginning)											
End Range	mm/dd/yyy	y	11:59 PM	(Leave	blank to sele	ct until end)						
Log Type:	Log Type: Telemetry Records 🔻											
Download	Log											
Delete Key	("delete"):		][	Delete Log								
Meta Data and Modbus Register Map												
File					Download			Up	load			
					Download	Meta Data		Cł	noose File	No file chose	en	

Meta Data	Download Meta Data	Choose File No file chosen
Modbus Register Map	Download Modbus Register Map	Choose File No file chosen Upload Register Map

#### Figure 40: PODD Site, Maintenance Tab

## **12 DCDC Emulator**

For those who wish to use the PODD device in advance of connecting peripheral Alencon devices, an emulator can be installed on the PODD for that purpose.

## **12.1 DCDC Emulator Functionality**

The emulator creates virtual SPOT or BOSS devices (not available with GARD) that communicate through the PODD Site as an actual connected device would, meaning all modbus registers available on the SPOT or BOSS will be accessible.

This is useful for testing the design of an external controller as the virtual DCDC device will receive and respond to commands as an actual device would. DCDC telemetry data will be accessible for reading through modbus TCP connection to the PODD.

The emulator does not mimic the power conversion of a DCDC device, it can't be used to model how a SPOT or BOSS will work to convert power in the customer specific application. Telemetry data values are assigned randomly, within typical ranges.

## 12.2 DCDC Emulator Enable and Disable

The PODD must be pre-configured for simulation mode by Alencon to run an Emulator. Please make known to your Alencon representative if you would like an emulator and what amount of virtual SPOT/BOSS devices should be included.

To use the PODD with actual Alencon devices, it must be transitioned from simulation to normal mode, please contact Alencon Technical Support to accomplish this.